




FRAME AND CONSOLE PARTS

For Models: DU948PWKB0, DU948PWKQ0
(Black) (White)

UNDERCOUNTER
DISHWASHER



Literature Parts

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	LIT3385181	Literature Parts Instructions, Installation	6		Console (Includes Insert & Active Overlay)	13	8275394	Harness and Protector
	LIT3367007	Instructions, Installation (Supplement) (Locating Your Water Supply)		8522137	Black	14	3376405	Elbow, Harness
	LIT3385283	Guide, Use & Care Tech Sheet		8522138	White	15	3400892	Screw
	LIT8528833	English	8		Door Frame	16	8051304	Cover, Timer
	LIT8528834	French		9743028	Black	17	3374501	Motor, Dual Panel, Front
	LIT8269375	Guide, Energy	9	3380854	Bolt, Latch	19	3379375	Black
3	3384563	Control, Electronic	10		Lever, Latch		3379376	White
4	3376359	Fuse, Thermal		3369457	Black	22	3379358	Spring, Door Catch
				3372231	White	23	3379357	Catch, Door
			11	3369325	Switch, (2)	26	3373234	Bearing, Spring (2)
			12	3368955	Pin, Switch (2)			


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INNER DOOR PARTS

For Models: DU948PWKB0, DU948PWKQ0

(Black)

(White)



Illus. No.	Part No.	DESCRIPTION
1	8051463	Door, Inner (Includes Items 2 & 3)
2	3376066	Latch, Detergent Dispenser (Includes Item 3)
3	3369061	Snap, Detergent Dispenser (Includes Item 2)
4	3369505	Actuator Assembly

Illus. No.	Part No.	DESCRIPTION
5	8052028	Wet Agent, Dispenser
6	3379673	Seal, Door Vent
7	3369448	Draw Bar, Electronic
8	3368999	Spring (Draw Bar)
9	3385001	Lid Assembly
10	8066018	Spring, Lid

Illus. No.	Part No.	DESCRIPTION
11	3372028	Pin (Lid Hinge)
12	3371710	Screen, Vent
13	3378134	Cap, Wet Agent
15	3400815	Screw (8)
16	3371569	Cover, Drip
19	3379674	Vent Assembly (Includes Item 6)
20	8271325	Absorber, Sound


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS

For Models: DU948PWKB0, DU948PWKQ0

(Black)

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS

For Models:DU948PWKB0, DU948PWKQ0

(Black)

(White)

Illus. No.	Part No.	DESCRIPTION
1	3378160	Tub Assembly
2	3380371	Tub, Wheel Assembly (8)
3	3368933	Runner (2)
4	3374849	Leveler (2)
5	3370389	Screw, Shoulder (2)
6	302819	Wheel (2)
7	343641	Screw, 10-16 x 1/2 (4)
8	3378149	Plate, Latch
9	3374720	Screw
10	3376927	Gasket
11	8283179	Barrier, Lower Vent
12	8528862	Deflector (2)
13	8519830	Heater (Includes Item 14)
14	717273	Washer, Rubber (2)
15	8268548	Nut (2) (Heater Terminal)
16	8283345	Water Valve
17	304392	Screw, 8-18 x 1/2

Illus. No.	Part No.	DESCRIPTION
18	661566	Thermostat, Hi-Limit
20	301958	Clamp
23	3400935	Clip
25	304231	Screw, 8-18 x 1/2
26	3374767	Insulation, Toe & Access Panel
28	3379383	Spring, Door (2)
29	8318218	Housing, Float Switch
30	3369067	Switch, Float
31	8318219	Cover, Switch Housing
32	8519587	Float & Washer Assembly
33	717488	Nut
34		Panel, Toe (Includes Item 26)
	3375423	Black
	9742869	White

Illus. No.	Part No.	DESCRIPTION
35		Panel, Access
	3384261	Black
	3384262	White
36	302868	Screw, 8-18 x 1/2 (4)
37	3369414	Hose, Inlet
39	3378123	Clip, Grounding
40	8271509	Sound Shield, Tub
41	8529303	Terminal Box
42	300068	Cover Assembly, Terminal Box
50	3378595	Bracket, Thermostat
53	3379740	Support, Heater
54	3400014	Screw
55	3378128	Washer
57	3369138	Screw, 8-18
58	304666	Retainer, Push (2)
61	8052018	Friction Pad

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


PUMP AND MOTOR PARTS

For Models: DU948PWKB0, DU948PWKQ0

(Black)

(White)

Note: The Pump Gasket Must Be Replaced Anytime The Pump Assembly Is Removed And Reinstalled In The Dishwasher.



PUMP AND MOTOR PARTS

For Models:DU948PWKB0, DU948PWKQ0

(Black)

(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9740982	Plate, Perforated (Includes Item 5) (Also Order Item 30) See Note A.	15	3369482	Check Valve (Includes Item 6)	29	8281183	Screw (4)
2	3367173	Base, Inlet (Includes Items 1 & 5) (Also Order Item 30) See Note A.	16	661633	Gasket, Pump	30	675505	Pump Seal Kit (Includes Items 4, 12, 13 & 22)
3	9741232	Screw, 8-18 x 5/8	17	3385002	Pump & Motor Assembly (Includes Item 16)	31	303918	Tool, Pump Centering
4	302710	Seal, Inlet Base	19	3378175	Chopper Kit (Also Order Item 30) See Note A.	32	356138	Clamp, Hose
5	302709	Ball, Check	22	302704	Seal, Drain Cover	33	3374077	Hose, Drain
6	95080	"O" Ring	23	3376845	Cover, Drain (Also Order Item 30) See Note A.	34	3371748	Cap, Drain
7	719929	Ball, Check	24	8274950	Impeller, Drain Kit (Also Order Item 30) See Note A.	35	3374757	Shaft, Absorber
9	3384593	Filter Assembly (Includes Items 12, 13 & 22) See Note A.	25	3376157	Base, Pump (Also Order ITEM 30) See Note A.	36	3378202	Weight, Absorber
10	3400001	Screw	26	3367197	Support, Pump Mounting (4)	37	9743158	Thermister
11	3378176	Impeller, Wash (Includes Items 12 & 13)	27	3368270	Slinger (See Note A.)	38	3376723	Seal, O-Ring
12	3371152	Screw & Seal 10-32 x 3/4	28	3377333	Motor & Fan Assembly (Includes Item 27) (Also Order Item 30) See Note A.	39	3376358	Retainer, Thermostat
13	302711	Seal, Pump Outlet				40	9740674	Gasket, Drain Cover
14	9742973	Outlet, Pump (Includes Item 13)						


NOTE A:
Pump Centering Tool Required
For Pump Re-Assembling
Order Item 31.

Note: The Pump Gasket
Must Be Replaced Anytime
The Pump Assembly Is
Removed And Reinstalled
In The Dishwasher.

Pump Centering Tool Required
For Pump Re-Assembling
Order Item 31.

UPPER DISHRACK AND WATER FEED PARTS

For Models: DU948PWKB0, DU948PWKQ0
(Black) (White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER DISHRACK AND WATER FEED PARTS

For Models:DU948PWKB0, DU948PWKQ0

(Black)

(White)


Illus. No.	Part No.	DESCRIPTION
1	9742953	Seal, Tube
2	661651	Tube, Water
5	3400919	Plug
8	3385160	Hanger, Water Inlet
9	8268852	Wheel Assembly
11	8268845	Manifold, Sprayarm
12	3376846	Seal, Sprayarm
13	8519604	Sprayarm, Upper
14	3385159	Mount
16	3400031	Screw
17	3379941	Stop, Track
18	3385089	Track, Dishrack
20	8519572	Dishrack, Upper
24	9743958	Tube, Feed
25	3379369	Wash Assembly w/ Slinger
26	3400850	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER DISHRACK PARTS

For Models:DU948PWKB0, DU948PWKQ0
(Black) (White)


Illus. No.	Part No.	DESCRIPTION
1	8519609	Dishrack, Lower
2	8268820	Wheel & Transport Assembly
4	8268869	Tinerow, Folding
6	8268522	Retainer, Tinerow
7	8268884	Silverware Basket Assembly
8	8519540	Door, Silverware Basket
9	8268886	Lid, Silverware Basket
10	8268874	Sprayarm, Lower
11	3376846	Seal, Lower Sprayarm
12	8268873	Nut, Sprayarm
13	9742946	Bearing, Radial
14	8268867	Clip, Silverware Basket (Left)
15	8268868	Clip, Silverware Basket (Right)
17	8519541	Latch Assembly



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models:DU948PWKB0, DU948PWKQ0
(Black) (White)



Illus. No.	Part No.	DESCRIPTION
1	3369816	Miscellaneous Parts Bag (Includes 2 Screws & 2 Hose Clamps)

OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	72107	Almond
	72032	Black
	4392899	Biscuit
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>		
	350956	Almond
	285006	Superior Black
	350942	Primer (White)
	4392901	Biscuit
<u>PAINT, TOUCH-UP (1 qt.)</u>		
	978883	Almond (Uncut)
	799340	Black (Uncut)
	4392900	Biscuit

Illus. No.	Part No.	DESCRIPTION
<u>DISHRACK REPAIR</u>		
	676453	Vinyl Touch-Up (White)
	675679	Tine Tip Repair Kit (White— Enough For Two Complete Dishracks)
	676455	Vinyl Touch-Up (Grey)
	676458	Tine Tip Repair Kit (Grey— Enough For Two Complete Dishracks)
	675652	Adhesive, Tine Tips

Illus. No.	Part No.	DESCRIPTION
<u>ACCESSORY PARTS</u>		
Side Panel Kits:		
	4317925	White
	4317929	Almond
Door Spring Kit:		
	4318050	Heavy Duty
<u>Following May Be Purchased</u>		
<u>DO-IT-YOURSELF REPAIR MANUALS</u>		
	LIT677967	Do-It Yourself, Manual

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST